



TempLite User Manual for Desktop

- 1 Download TempLite Windows Application from the Temprecord Website.
<https://temprecord.com/our-software/templite-windows/>
- 2 Install TempLite Windows using the **TempLite.exe** file
- 3 Connect your Temprecord Reader to your Computer
- 4 Open TempLite
- 5 If this is the first image you see, Connect your Temprecord Reader to your computer.




- 6 If you are here, you are ready to read our Temprecord Loggers. Once you insert a logger into reader, the following process (7, 8, 9) will happen automatically.




7

The logger is being read.
DO NOT remove the logger from the reader until this process has finished.




8

When the logger has been read, EXCEL and PDF documents will be generated.
(At this stage, it is safe to remove the logger.)



9

Once the documents have been generated, you will have the option to preview and email the generated files.



10

If you would like to read another logger, Remove the current logger out of reader, and insert the new logger in the reader, then PRESS the “READ LOGGER” button.